



G4000 Handrail

3 Bracket Styles



Product Guide



- ① 1 1/2" (38mm) x 2" (51mm) gripping surface
- ① Mounted on a continuous Forest Stewardship Council (FSC) certified wood retainer
- ① .110" (2.8mm) thick high density polyethylene (HDPE) cover
- ① Manufactured in 12' (3.66m) standard lengths
- ① Meets ADA and ANSI criteria
- ① Three available bracket styles
- ① All mounting fasteners are included with each order



IPC.587/REV.4

G4000 Handrail

Suggested Specifications

PART 1 - GENERAL

1.01 SUMMARY

A. Handrail system that is environmentally friendly and provides pedestrian safety, and wall protection

1.02 SECTION INCLUDES

A. G4000 Handrail System

1.03 REFERENCES

- A. American National Standards Institute (ANSI)
- B. American Society for Testing and Materials (ASTM)
- C. Americans with Disabilities Act (ADA)
- D. National Fire Protection Association (NFPA)
- E. Society of Automotive Engineers (SAE)

1.04 QUALITY ASSURANCE

- A. Performance Requirements: Provide handrail systems that conform to the following requirements of regulatory agencies and the quality control of IPC Door and Wall Protection Systems, InPro Corporation.
- 1. Fire Performance Characteristics: Provide handrails conforming with NFPA Class B fire rating. Surface burning characteristics, as determined by ASTM E-84, shall be flame spread of 50 and smoke development of 170.
- 2. Chemical and Stain Resistance: Provide handrails that show resistance to stain when tested in accordance with applicable provisions of ASTM D-543.
- 3. Fungal and Bacterial Resistance: Provide snap-on cover that does not support fungal or bacterial growth as tested in accordance with ASTM G-21 and ASTM G-22.
- 4. Color Consistency: Provide components matched in accordance with SAE J-1545 - (Delta E) with a color difference no greater than 1.0 units using CIE Lab, CIE CMC, CIE LCh, Hunter Lab or similar color space scale systems.
- 5. System Impact Resistance: Provide a handrail system that resists an impact of 58.6 ft-lbs while producing no visual blemishes upon the cover surface and no deformation in the wood retainer as tested in accordance with applicable provisions of ASTM F 476-84, paragraph 18, Impact Test.
- 6. Code Compliance: Provide handrails that comply with all current ANSI and ADA requirements.

1.05 SUBMITTALS

- A. Product Data: Manufacturer's printed product data for each type of handrail specified.
- B. Detail Drawings: Mounting details with the appropriate fasteners for specific project substrates.
- C. Samples: Verification samples of handrail, 8" (203mm) long, in full size profiles of each type and color indicated.
- D. Manufacturer's Installation Instruction: Printed installation instructions for each handrail.

1.06 DELIVERY, STORAGE AND HANDLING

- A. Deliver materials in unopened factory packaging to the jobsite
- B. Inspect materials at delivery to assure that specified products have been received.
- C. Store in original packaging in a climate controlled location away from direct sunlight.

1.07 PROJECT CONDITIONS

- A. Environmental Requirements: Products must be installed in an interior climate controlled environment.

1.08 WARRANTY

- A. Standard IPC Limited Lifetime Warranty against material and manufacturing defects.

PART 2 - PRODUCTS

2.01 MANUFACTURER

- A. Acceptable Manufacturer: IPC Door and Wall Protection Systems, InPro Corporation, PO Box 406 Muskego, WI 53150 USA; Telephone: 800-222-5556, Fax: 888-715-8407, Internet address: <http://www.inprocorp.com>
- B. Substitutions: Not permitted
- C. Provide all handrails and wall protection from a single source.

2.02 MANUFACTURED UNITS

A. Handrail Profile

- 1. G4000 Handrail, 1-1/2" (38mm) x 2" (51mm) gripping surface, extends 3-1/2" (89mm) from wall.

2.03 MATERIALS

- A. High Density Polyethylene: Snap-on covers of .110" (2.8mm) thickness shall be extruded from chemical and stain resistant high density polyethylene.
- B. Wood: Continuous solid wood retainer shall be milled of sealed, kiln dried, FSC Certified Ash.

C. Stainless Steel: Stainless Steel Brackets shall be made of type 304 stainless steel.

2.04 COMPONENTS

- A. Returns, inside corners, outside corners and brackets shall be made of injection molded thermoplastics.
- B. Fasteners: All mounting system accessories appropriate for substrates indicated on the drawing shall be provided, unless installer supplied is indicated.

2.05 FINISHES

- A. High Density Polyethylene Covers: Handrail colors to be selected by the architect from the IPC finish selection. Surface shall have a pebblette texture.
- B. Molded components: Inside corners, outside corners, returns and brackets shall be of a color matching the handrails. Surface shall have a pebblette texture.
- C. Stainless Steel: Stainless steel brackets shall have a satin finish.

PART 3 - EXECUTION

3.01 EXAMINATION

- A. Examine areas and conditions in which the handrail systems will be installed.
- 1. Complete all finishing operations, including painting, before beginning installation of handrail system materials.
- 2. Wall surface shall be dry and free from dirt, grease and loose paint.

3.02 PREPARATION

- A. General: Prior to installation, clean substrate to remove dust, debris and loose particles.

3.03 INSTALLATION

- A. General: Locate handrail as indicated on approved detail drawings for the appropriate substrate and in compliance with the IPC installation instructions. Install handrail level and plumb at the height indicated on the drawings.
- B. Installation of G4000 Handrail: Material must be stored, installed and used in environmentally controlled conditions
 - 1. Cut the wood retainer to desired length, leaving appropriate allowance for the returns, inside corners and outside corners. Allow 5-7/16" (138mm) for each return, 1/16" (2mm) for each inside corner and 3/16" (5mm) for each outside corner. Allow 3/16" (5mm) for each 135° outside corner and 2-3/16" (56mm) for each 135° inside corner.
 - 2. Drill holes in the centerline of the wood retainer for brackets, using a 5/16" drill bit. Holes should be 4" (102mm) from the ends and spaced a maximum of every 32" (813mm).
 - 3. Attach the brackets to the wood retainer using one #12 x 3/4" Phillips pan head screw for each bracket. Attach returns, inside corners and outside corners to the wood retainer using one #12 x 3/4" Phillips pan head screws (one per return and two per corner). Important: Pre-drill the wood in order to prevent splitting. To allow for adjustment, leave at least a 1/16" (1.5mm) gap between the returns/corners and the end of the aluminum retainer when sliding the two components together.
 - a. Stainless Steel Brackets - The posts on stainless steel brackets are threaded. Slip either the plastic cover or stainless steel cover over the post and then insert the threaded post through the hole on the retainer. Attach the post to the retainer with a 1/4" lock washer and a 1/4" hex head nut.
 - 4. Position the wood retainer/bracket assembly against the wall at the desired height. Level the retainer and transfer the locations of the bracket holes to the wall with a marker. Drill all marked holes on the wall with a 3/4" drill bit for toggle bolts or a 1/2" drill bit for lead anchors.
 - 5. Loosely attach the mounting bolts to the brackets (one 1/4" -20 x 5" hex head screw with phillips head slot, one 1/4" lock washer and one toggle wing or lead anchor for each bracket). For stainless steel brackets, use one 1/4"-20 x 3" hex head screw with phillips head slot, one 1/4" lock washer and one toggle wing or lead anchor. Mount the wood retainer assembly into the holes on the wall using the provided fasteners. Level and secure the retainer to the wall.
 - a. Stainless Steel Brackets - After the handrail is level and the brackets are securely attached to the wall, snap either the molded cover or stainless steel cover over the mounting base.
 - 6. Cut the cover to the distance between the returns and/or corners. NOTE: Trim all factory edges square before installation. (Cutting the cover 1/32" longer will help in achieving a tight fit). Position the cover on the wood retainer at one end. Work to the other end by pushing the cover over the wood until it snaps into place.
 - 7. Left and right returns should be screwed into the wall and/or retainer for added strength. Remove the bottom plate on the return and fasten screws (provided by the installer) into the wall and/or retainer through the holes located underneath the return. Re-attach the bottom plate by snapping into place.

3.04 CLEANING

- A. At completion of the installation, clean surfaces in accordance with the IPC clean-up and maintenance instructions.

P.O. Box 406 · Muskego, Wisconsin 53150 USA

www.inprocorp.com

Nationwide **800.222.5556**/Fax 888.715.8407

International Sales **262.679.5521** / Fax 262.679.5524